

# **Petro 3003**

## **Quick Guide**

## **VOLUTANK**

(Without SAFE, with wet hose, with collector draining, with company select)

Softwareversion PYRAMIDE 2.5.x

KBA 210327


**PLEASE NOTE**

*This document is a short version of the product operation. It must be kept in the immediate vicinity of the device so that access to it is possible at any time.*


*To be observed safety and more detailed instructions, see the operation manual.*

*The current version can be downloaded from [www.bartec.de](http://www.bartec.de) or requested from BARTEC BENKE GmbH.*


# Loading without SAFE




# Loading with company select




## Filling the compartments



## Compartments filled




## 2. Closing the load menu







## 1. Closing bottom valves

## Choosing the compartment




## Assign products




# Delivery without SAFE




# Wet hose delivery parallel



# Wet hose delivery seriell






# Wet hose part delivery







# Collector draining



## Draining the collector



# Display of operating states

