BCS3600ex-NI Hand-held scanner

Accessories

It is absolutely necessary to use original accessories from BARTEC!

BARTEC

Accessories for use in hazardous areas

Accessories are approved for:

- ATEX: Zone 2/22 (EPS 16 ATEX 1 113 X)
- IECEx: Zone 2/22 (IECEx EPS 16.0050X)
- NEC: Class I, II, III Div. 2 (ETL 5012876)

Battery

Description	– for BCS3678ex-NI Hand-held scanner – Lithium-Ion battery 3.6 V/3150 mAh (11.34 Wh) May only be changed and charged outside hazardous areas!
Order no.	B7-A2Z0-0036

Leather holster

Description	– for attachment to a belt or wall – Color: black
Order no.	17-A1Z0-0024

Connecting cable

Description	– Connection between supply module and BCS3608ex-NI Hand-held scanner	
Order no.	1.9 m (plain)	B7-A2Z0-0037
	4.5 m (plain)	B7-A2Z0-0038
	2.7 m (spiral)	B7-A2Z0-0039

HMI limiting cable

Description	– Connection between HMI and BCS3608ex-NI Hand-held scanner – with open cable ends	
Order no.	1.9 m (plain), USB	B7-A2Z0-0041
	4.5 m (plain), USB	B7-A2Z0-0054

BARTEC

Accessories for use outside hazardous areas

4-slot battery charging station

Description	– for BCS3678ex-NI Hand-held scanner
	– input voltage: DC 12 V (50 W)
	– Charging indicator via LED
Scope of delivery	4-slot battery charging station
Also required	(Not included in the delivery)
	– Power supply with DC connecting cable (G7-A0Z0-0019)
	– AC power cable
Order no.	G7-A0Z0-0013

Base station

Description	– for BCS3678ex-NI Hand-held scanner
	– Input voltage: DC 12 V
	– Data synchronisation via Bluetooth, Supported interfaces (full functionality as specified by Zebra): USB + RS232
	– Charging the battery inserted in the hand-held scanner
	– Charging function and charging indicator via LED
	– can be mounted on wall or table
	Operating mode:
	– Point-to-Point (1x scanner paired with 1x base station - default setting)
	– Multipoint-to-Point (7x scanners can be paired with 1x base station)
Scope of delivery	Base station
Also required	(Not included in the delivery)
	– Power supply with DC connecting cable (G7-A0Z0-0019)
	– AC power cable
	– Connecting cable (G7-A0Z0-****)
	* Connecting cable absolutely necessary between power supply and base station. Power supply cannot be connected directly to the base station.
Order no.	G7-A0Z0-0010

Programming cable USB

Description	– for programming BCS3608ex-NI and BCS3678ex-NI via PC
	– supports connection via USB only
	– 1.9 m (plain)
Scope of delivery	Programming cable USB
Also required	(Not included in the delivery)
	– Base station (when using the BCS3678ex-NI)
Order no.	B7-A2Z0-0046

BARTEC

Connecting cable

Description	– for BCS3678ex-NI Hand-held scanner – Connection between PC and base station – Cable with terminal for 12 V power supply	
Scope of delivery	Connecting cable	
Also required	(Not included in the delivery)	
	– Power supply with DC connecting cable (G7-A0Z0-0019) – AC power cable	
Order no.	RS232: 2.0 m (plain)	G7-A0Z0-0014
	RS232: 4.6 m (plain)	G7-A0Z0-0015
	RS232: 2.8 m (spiral)	G7-A0Z0-0016
	USB: 2.0 m (plain)	G7-A0Z0-0018

Power supply with DC connecting cable

Description	– for 4-slot battery charging station and base station
	– Input voltage: AC 100 to 240 V
	– Output voltage: DC 12 V/4.16 A/50 W
Order no.	G7-A0Z0-0019

AC power cable

Description	– 3-wire – country-specific	
Order no.	Version: US + Canada	G7-A0Z0-0024
	Version: EU + APAC	G7-A0Z0-0026
	Version: Taiwan	G7-A0Z0-0027
	Please purchase the required country specific cables (with plug IEC-60320-C13) in the respective country!	

Special tool for lock nut

Description	– for BCS3678ex Hand-held scanner
	– open and lock the safety lock nut on the battery compartment
	– 5 pieces
Order no.	G7-A0Z0-0031